



Part No	Description
01	Motor Pedestal
02	Coupling (Complete)
02E	Coupling Element
02.1	Motor Coupling
02.2	Pump Coupling
03	Thrust Bearing Housing
04	Bearing Pedestal
05	Thrust Bearing 3316 E C3
06	Lock-Nut & Washer
07	Bearing Retaining Ring
08	Snap Ring Dia 90 ext.
11	Shaft
12	Upper Column
13	Lower Column
14	Lower Bearing NU2319 EC3
15	Suction Inlet
16.1	Casing - Volute
16.2	Casing - Skirt
17	Impeller
18	Flinger
19	Seal Ring
20	Gland Packing
24	Bearing Cartridge Assembly
25	Shaft Sleeve
26	Pump Bracket
27	Casing Insert
28	Lower Bearing Spacer
29	Lower Bearing Housing
30	Retaining Plate
31	Gland Follower
33	Enducer
Fasteners	
F1	Bolt & Nut: Motor to Motor Pedestal
F2	Bolt: Thrust Brg Housing to Brg Pedestal
F3	Bolt: Motor Pedestal to Upper Column
F4	Bolt & Nut: Upper Column to Lower Column
F5	Bolt: Lower Column to Casing Skirt
F6	Bolt: Casing to Suction Inlet
F7	Cap Screw: Agitator to Shaft
F8	Bolt: Upper Column to Retaining Plate
F9	Bolt & Nut: Lower Column to Gland Follower
F10	Bolt: Casing Skirt to Casing Volute

